



Ten - Air Breeze Exploded Views & Parts List





item	item number	item name				
1	3-CMBP-2015-01	NOSECONE - LAND	13	3-CAOT-1002	O-RING	
	3-CMBP-2015-02	NOSECONE - MARINE		3-CMBP-2019-01	BODY ASSEMBLY II - AIR BREEZE - LAND - 12V (SEE VIEW #2)	
2	3-HDBT-1000-06	SCREW - SOCKET HEAD - 1/4 20 X 1 1/4" - SS	14	3-CMBP-2019-02	BODY ASSEMBLY II - AIR BREEZE - LAND - 24V (SEE VIEW #2)	
	3	3-HDWA-919		3-CMBP-2019-03	BODY ASSEMBLY II - AIR BREEZE - LAND - 48V (SEE VIEW #2)	
4	3-HDNT-100-13	NUT - JAM - SAE - 5/8-18 - ZINC		3-CMBP-2019-04	BODY ASSEMBLY II - AIR BREEZE - MARINE - 12V (SEE VIEW #2)	
5	3-CMBP-2017-01	BLADE - AIR BREEZE - LAND		3-CMBP-2019-05	BODY ASSEMBLY II - AIR BREEZE - MARINE - 24V (SEE VIEW #2)	
	3-CMBP-2017-02	BLADE - AIR BREEZE - MARINE		3-CMBP-2019-06	BODY ASSEMBLY II - AIR BREEZE - MARINE - 48V (SEE VIEW #2)	
6	3-CMBP-2016-01	HUB - AIR BREEZE-LAND		15	3-CAOT-1006	SNAP RING - 32MM EXTERNAL
	3-CMBP-2016-02	HUB - AIR BREEZE-MARINE	16	3-CMBP-1004-01	YAW SHAFT - AIR - LAND - 34"WIRES	
7	3-HDNT-102-05	NUT - NYLOCK - SAE - SS - 6-32	16	3-CMBP-1004-04	YAW SHAFT - AIR - MARINE - 34"WIRES	
	8	3-HDBT-1000-577		SCREW - SOCKET HEAD - 10-24 X 1-1/2"		
9	3-CMBP-1013-01	FACE ASSEMBLY - AIR - LAND	17	3-HDBT-9000	SCREW - TAPTITE - 8/32 X 1"	
	3-CMBP-1013-02	FACE ASSEMBLY - AIR - MARINE		3-CMBP-2020-01	CIRCUIT AND RECTIFIER TOTAL ASSEMBLY -12V	
				3-CMBP-2020-02	CIRCUIT AND RECTIFIER TOTAL ASSEMBLY -24V	
10	3-CMBP-1341	STATOR ISOLATOR	18	3-CMBP-2020-03	CIRCUIT AND RECTIFIER TOTAL ASSEMBLY -48V	
	3-CMBP-1019-02	STATOR - AIR (FOR 12V BREEZE)		19	3-CMBP-1033	WIRE HARNESS - POTENTIOMETER
				3-CMBP-1019-03	STATOR - AIR (FOR 24V BREEZE)	20
3-CMBP-1019-05	STATOR - AIR (FOR 48V BREEZE)	21	3-CMBP-1011-01			BODY ASSEMBLY I - AIR LAND
11	3-CMBP-1019-05	STATOR - AIR (FOR 48V BREEZE)	21	3-CMBP-1011-02	BODY ASSEMBLY I - AIR MARINE	
				22	3-HDWA-101-07	WASHER - EXT STAR WASHER SS 1/4"
12	3-CMBP-1313	ROTOR - AIR	23	3-HDNT-101-12	NUT - JAM - SAE - SS	